



# QUICK REFERENCE GUIDE

Valid for Battery-Box L 3.5/7.0/10.5/14.0

## Target Group

V 5



Skilled personnel only

This manual and the tasks and procedures described herein are intended for use by skilled workers only.

A skilled worker is defined as a trained and qualified electrician or installer who has all of the following skills and experience:

- Knowledge of the functional principles and operation of on-grid systems.
- Knowledge of the dangers and risks associated with installing and using electrical devices and acceptable mitigation methods.
- Knowledge of the installation of electrical devices.
- Knowledge of adherence to this manual and all safety precautions and best practices.

## Installation environment requirements

Max. +50°C	Min. -10°C	RH. +5%~+95%
<p><b>NO</b> </p> <p><b>NO</b> </p>		

<b>Tools</b>	Wire clamp	Torque wrench	Precision screwdriver	Inclinometer	Wrench	Churn drill
--------------	------------	---------------	-----------------------	--------------	--------	-------------

## Packing list

Packing of BCU+BASE					Packing of B-Plus L 3.5
① 4× M6	② 1×M8	③ 1×M10	④ 3×Expansion bolt M6	⑤ WIFI module	⑥2×M6

## Overall structure

Battery-Box L 3.5

Battery-Box L 7.0

Battery-Box L 10.5

Battery-Box L 14.0

BCU


B-Plus

Base


# Installation steps

## 1. Unpacking


BCU + Base+Accessories



\*n=1-4 B-Plus L 3.5




## 2. Install anchor bolt & Leveling




## 3. Install B-Plus & BCU

The BCU screws are not locked. After installing the hangers, tighten the screws.




## 4. Install the hangers

- 4.1 Use a pencil to mark the location of the hole to be drilled.
- 4.2 Remove the BCU, punch holes in the wall with hammer drill.
- 4.3 Install expansion bolt in punched holes.
- 4.4 Install the BCU, then lock the crews and expansion bolt.




## 5. Open the BCU cover

- 5.1 Remove the screw from the measuring surface.
- 5.2 Push the cover to the right, then lift it up.




## 6. BCU internal overview




## 7. Power cables, ground cable, Communication cable & WIFI cables connection

1-8



RJ45 Pin define

	Battery-Box	SMA	GOODWE	VICTRON	SUNGROW	Solis
CAN H	4	4	4	7	CAN H	4
CAN L	5	5	5	8	CAN L	5



**Inverter**  
CAN - +



WIFI  
CAN BCU1 BCU2

## 8. Install wifi module

8.1 Connect the wifi cable to the wifi module.

8.2 Install the wifi module.


Turn the knob counterclockwise when connect the wifi cable to the wifi module.



When installing WIFI module, the LED lights are facing out.



## 9. Installation complete for single system



## 10. Setting SOC parameters & advice


In order to protect the battery, we recommend that the battery retain some power. Please follow the table

battery damage. And such damage is outside the warranty.

TYPE	On grid	Backup
Battery-Box L 3.5	15%	20%
Battery-Box L 7.0	10%	20%
Battery-Box L 10.5	10%	20%

Please refer to the installation manual of this product and setting.

## 11. Installation complete for parallel system



If connecting 3 BCU in parallel, unplug the jumper on the second BCU PCBA.



If connecting 2 BCU in parallel, Don't unplug the jumper.



## 12. WIFI setting

You can use a computer, mobile phone or IPAD to set up and configure.

Power




## 13. Update the Battery-Box firmware

### Reminder:

There are two ways to update the firmware for BCU: over the WIFI connection and over the cable connection.


Update via WIFI connection: the entire update process takes about 1 minutes.  
Update via cable connection: update methods are available at the following Web site. Or scan the QR code to visit the site for more information.  
<http://alpspower.com.au/download/>  
<http://www.eft-systems.de/de/downloads>




Europe

## 14. Checking the status of the Battery-Box

checking the battery status by typing the URL




## 15. Configure the network



\*After clicking "OK", you need to wait for 10 seconds to close the webpage. Otherwise, the configuration is unsuccessful. Need to reconfigure.

## 16. WIFI status indicator

If your WIFI signal is weak, it is recommended to add a WIFI amplifier.



LED Status	Meaning	Disposal measures
	Successful network configuration.	
	Network configuration is unsuccessful.	Reconfigure the network. Confirm network password
	Normal communication between antenna and BCU.	
	Communication between antenna and BCU is abnormal.	Check the connection of WIFI and BCU Replace WIFI components.
	WIFI antenna is working properly.	
	WIFI antenna failure.	Replace WIFI components.

## 17. System status indicator

Power



	Diagram	Status	Meaning
1		White blink slow	Charging
2		White blink fast	Discharging
3		White always ON	Idle
4		White blink very slow	Idle
5		Orange blink 2 times	System WIFI is lost
6		Orange blink 3 times	Loss of inverter communication
7		Orange blink 4 times	Lost slave CAN communication
8		Orange blink 5 times	Uncalibrated
9		Orange always ON	BCU or Battery failure